
RZAG100-140MV1 RZAG100-140MY1 **RZASG100-140MV1 RZASG-MY1**



Liquid receiver Heat exchanger Electronic expansion valve 4-way valve Service port 5/16" flare High pressure switch Low pressure switch Compressor Compressor Accumulator Stop valve

Stop valve ____ Distributor Check valve Solenoid valve Capillary tube

Notes

1. The pipes between the branch and the indoor units should have the same size as the indoor connections.