
FCAG-B

1. Location of nameplate

- The unit nameplate is located on the control box cover.
- The decoration panel nameplate is located on the piping-side panel frame, under the corner cover,
- When installing optional accessories, refer to their respective documentation.
- 3 Make sure the distance between the ceiling and the cassette does not exceed .35 mm.
- The maximum ceiling opening is .910-mm.
- 4. When the conditions in the ceiling exceed 30°C ambient temperature and 80% relative humidity, or when fresh air is inducted into the ceiling, additional insulation is required (polyethylene foam, thickness ≥ 10 mm).
- When installing a sensor kit, there will be a sensor on this location. For details, see the drawing of the sensor kit.



installation space on that (closed up) side is .500 mm instead of .1500 mm.

Knockout hole