FTXP50-71M

Wiring diagram



FG, HE, S6 S900	Connector
F1U (FU1)	Fuse
T1R (L301)	Transformer
M1F	Fan motor
M1S, M2S	Swing motor
K1R (MR10)	Magnetic relay
A1P~A4P	Printed circuit board
R1T, R2T	Thermistor
BS1 (S1W)	Operation switch
R2V (V2)	Varistor
X1M	Terminal strip
Z1C, Z2C	Ferrite core
IPM201 203	Intelligent power module
H1P, H2P (LED12)	Pilot lamp
⏚	Protective earth
V1R (DB301)	Diode bridge
H1 (BZ)	Buzzer
C101~302	Capacitor
SR (WLU)	Signal receiver

BLK: black
RED: red
BLU: blue
WHT: white
GRN: green
YLW: yellow
ORG: orange

Caution

When the main power is turned off and then back on again, operation will resume automatically.

NOTES:

1. Size: length ·65· X width ·110·.
2. Refer to purchasing specification ·AS303002·, unless otherwise specified.

3D118438